

SECTION 4 CHAPTER 3 WORKING WITH ELECTRICAL EQUIPMENT

Purpose	The training requirements of Gravity Oilfield Services' electrical safety program contained in this chapter apply to employees who face a risk of electric shock that is not reduced to a safe level and who are not qualified persons shall also be trained in and be familiar with any electrically related safety practices not specifically addressed but which are necessary for their safety. Unqualified employees must maintain a 10' clearance distance. The training requirements of Gravity Oilfield Services' electrical safety program contained in the chapter does not apply to employees who are qualified to face a risk of electric shock that is not reduced to a safe level. Their training requirements are not covered in this manual and any work requiring that level of training and knowledge shall not be done by Gravity Oilfield Services' employees.	
Scope	This procedure applies to all Company personnel working with or near electrical equipment, including those involved with the: • setting up a safe workplace • use of: • • extension cords • electrical power tools • welding equipment • equipment grounding and bonding	
In this chapter		
	Торіс	See page
		2

Торіс	See page
Setting Up a Safe Workplace	2
Using Extension Cords Safely	3
Working with Electrical Equipment	4
Working Near Overhead Power Lines	6
Controlling Static Electricity	7



Setting Up a Safe Workplace

Purpose This document describes information and policies regarding electrical safety in the workplace, including:

- hazards
- signs and labels
- wiring

Hazards

The hazards of working with exposed, energized electrical equipment include:

- electrical shock
- static electricity
- electrical short
- ignition in a flammable atmosphere
- fire and explosion

Signs and labels Designated company employees will post the following signs:

- signs reading "Danger High Voltage" in high-voltage areas
- signs reading "Danger Electrical Hazard" in areas with exposed energized parts.



Checking wiring Make visual inspections to ensure that wires are:

- completely insulated
- not exposed to wash bay or wet areas
- have no signs of overheating or short circuiting
- junction boxes are in place for wiring systems and are covered properly



Using Extension Cords Safely

Purpose	This section describes safety guidelines for the use of extension cords.		
Location	 Do not locate extension cords where they will: stand in water create a tripping hazard be damaged by equipment or vehicles 		
Using extension cords	 Do not use: extension cords as a replacement for permanent wiring multiple connected extension cords defective or altered extension cords (e.g. with the ground prong removed, spliced or taped) Use Ground Fault Circuit Interrupters (GFCIs) with extension cords in the following situations: outdoors near water for tools or equipment being used in a confined space near flammable or combustible materials during wet installations such as: sinks tanks Inspect the extension cords for: exposed wiring bad plugs defective prongs flattened areas Take damaged cords out of service and repair them. IF the cord has been flattened or the ground prong missing, THEN throw it away. 		



Working with Electrical Equipment

Purpose

Safety-related work practices shall be implemented to prevent electric shock or other injuries resulting from either direct or indirect electrical contacts. When work is performed near or on equipment or circuits which are or may be energized, efforts must be made to de-energize equipment. Policies involved in these work practices include, but not limited to:

- personnel
- tools, protective equipment and training
- procedures for beginning work
- working safely

When efforts to de-energize equipment have been completed, Lock Out/Tag Out procedures must be utilized. If conductors and parts of electrical equipment that have been de-energized, but have not been locked or tagged out, shall be treated as live parts.

For more information see chapter on Lockout/Tagout.

Personnel

Only *qualified persons (contractors)* may work on or repair energized or de-energized electrical equipment and systems. A qualified person is one who has completed an apprenticeship and received training covering the:

- topics required by 29 CFR 1910.331-.335 AND
- electrical hazards of working on or near exposed, energized parts

No company employees are allowed to perform maintenance or repair on electrical equipment and systems.

During repair or maintenance of electrical equipment or systems by Qualified Persons (Contractors) protective shields, protective barriers or insulating materials must be in place where hazards exist. Employees may not enter spaces containing exposed energized parts until repair and maintenance is completed.

Ladders with nonconductive (fiberglass) side rails must be used in areas where there is a chance that employees might contact exposed energized circuit parts.



Tools, protective equipment and training	practices required by their respective job assignments. Assignments
	include, but not limited to:electrical components of vehicles

- powered equipment
- powered hand tools
- electrical panel boxes

Beginning work Follow this procedure beginning work.

Step	Action
1	Remove the following items from your person:
	• jewelry, including:
	o rings
	0 earrings
	0 necklaces
	• watches
	• keys
	• lighters
	similar metallic objects
2	De-energize equipment before beginning work.
3	Follow lockout/tagout procedures to prevent re-energizing.

Working safely While working, follow these guidelines.

- ensure LO/TO has been performed and equipment is in a "Zero" energy state
- Do not remove, bypass, modify LO/TO procedures.
- Consider all equipment energized, unless confirmed otherwise.
- Never leave exposed energized parts unattended.
- Never work on energized equipment.



Working Near Overhead Power Lines

Rig or truck in transit (lowered mast)

Purpose	This section describes the s power lines.	afety procedu	res for working near overhead
Before beginning work	Consider all power lines energized unless a qualified person has de-energized them.		
	performing any work near	overhead pow	field production operator before er lines. While working near to hit the lines or tear them down.
Moving machines in the shop	Always use a spotter when hitting internal power lines	-	ines or rigs in the shop to avoid
Minimum clearance for outside lines	Observe the minimum distances listed in the following table when operating equipment or machines on rigs (including guylines). No part of the rig, truck or auxiliary equipment may come closer to the power lines than the distance shown.		
	Rig or Truck Status	Line Voltage, Volts	Minimum Clearance in Feet
	Operating rig or truck	ANY	10 (305 cm)
	(raised mast)		plus the height of derrick or mast, plus attachments, e.g., antennas
	Rig or truck in transit (lowered mast)	Up to 50,000	10 (305 cm)
	Rig or truck in transit (lowered mast)	50,000 to 345,000	10 (305 cm)

345,000 to

750,000

16 (487 cm)



Controlling Static Electricity

Purpose	This section describes the hazards created by static electricity and methods for reducing the danger.		
Hazard	Windy and dry conditions can generate static electricity. The sparks generated by static electricity can set off the explosives used in well servicing operations, or hydrocarbon vapors around a well or production facility.		
Methods of control	 Static electricity can be controlled by: bonding grounding reducing flow rate or dissipating en minimizing agitation using properly designed equipment 	ergy over time	
Bonding and grounding during operations	 To bond equipment during operations: 1. attach a cable or 6 foot copper rod that is long enough to touch the ground to the equipment 2. verify that the cable is touching the ground 3. attach a ground cable from rigs to wellhead/flowline Use these bonding procedures to prevent the release of static electricity. 		
	Before	ground the equipment by bonding the	
	transferring flammable liquids between containers,	containers to a common ground	
	transferring flammable liquids from a permanent storage tank to a truck- mounted transport or truck to truck,	transport to the tank	
	beginning pulling rods or tubing before pumping flammable liquids to a well with a pump truck	rig to the wellhead or flowline truck frame to the well with a cable and clamp	
	beginning work with a perforating or logging truck	truck frame to the wellhead	